

**Table 6-2 RamWorks basic Bank Configuration Chart**

<b>RamWorks basic Main Board: Block    Size    Bank Numbers (hex notation)</b>						
	A	64K	\$00	-	-	-
		256K	\$00	\$04	\$08	\$0C
	B	64K	\$03	-	-	-
		256K	\$03	\$07	\$0B	\$0F
<b>512K Memory Expander: Block    Size    Bank Numbers</b>						
	E	64K	\$01	-	-	-
		256K	\$01	\$05	\$09	\$0D
	F	64K	\$02	-	-	-
		256K	\$02	\$06	\$0A	\$0E
<b>2 Meg. Memory Expander: (discontinued) Block    Size    Bank Numbers</b>						
	E	256K x 8	\$01	\$02	\$05	\$06
	F	256K x 8	\$09	\$0A	\$0D	\$0E
	G	256K x 8	\$21	\$22	\$25	\$26
	H	256K x 8	\$29	\$2A	\$2D	\$2E
	I	256K x 8	\$41	\$42	\$45	\$46
	J	256K x 8	\$49	\$4A	\$4D	\$4E
	K	256K x 8	\$61	\$62	\$65	\$66
	L	256K x 8	\$69	\$6A	\$6D	\$6E
<b>2 Meg Plus Memory Expander: Block    Size    Bank Numbers</b>						
	A	1 Meg	\$01	\$02	\$05	\$06
			\$09	\$0A	\$0D	\$0E
			\$21	\$22	\$25	\$26
				\$29	\$2A	\$2D
			\$2E			
	B	1 Meg	\$41	\$42	\$45	\$46
			\$49	\$4A	\$4D	\$4E
			\$61	\$62	\$65	\$66
			\$69	\$6A	\$6D	\$6E