

PR#3  
:ASM

```
0800 *ROM HACK PART 1
0805 *WE INTERCEPT THE RESET VECTOR HERE
0900 *THIS ROUTINE BANK SWITCHES TO THE
0905 *INTCX ROM BANK AND JUMPS TO OUR
0910 *REAL ROM HACK CODE AT $C600 ROM
0915 *IF THE USER DOES NOT BREAK INTO THE
0916 *THE MONITOR, THEN THE C600 ROUTINE (PART 2)
0917 *WILL JMP BACK HERE FOR NORMAL EXIT
C600- 1000 ROMHAK .EQ $C600 OUR REAL CRACK IS HERE
C007- 1005 INTCX .EQ $C007 INTCX BANK TOGGLE ADDR
C006- 1007 SLOTCX .EQ $C006 NORMAL SLOTCX BANK TOGGLE
FA62- 1008 OLDVEC .EQ $FA62
      1010      .OR $FEFD
      1020      .TA $800
FEFD- 8D 07 C0 1040      STA INTCX TOGGLE TO INTCX ROM BANK
FF00- 4C 00 C6 1050      JMP ROMHAK AWAY WE GO
FF03- 8D 06 C0 1060 NORMAL STA SLOTCX      NORMAL EXIT
FF06- 4C 62 FA 1070      JMP OLDVEC
```

#### SYMBOL TABLE

C007- INTCX  
FF03- NORMAL  
FA62- OLDVEC  
C600- ROMHAK  
C006- SLOTCX

0000 ERRORS IN ASSEMBLY  
: